

FRONT SHOCK ABSORBER PRODUCT IDENTIFICATION

Strut mount kit : MK184
Citroën C2 / C3

FI117EU



C2
(model 9.03 >> 12.09)



C3
(model 2.02 >> 12.10)



C2 9.03 >> 8.04
C3 2.02 >> 8.04
to n° PR* 10156

MK184 (strut mount kit + bearing)



OU

MK001 (bearing)



C2 8.04 >> 12.09
C3 8.04 >> 12.10
from n° PR* 10157

MK001 (bearing)



* n° PR : Spare part number

| TORQUE | daN.m |
|---|-------|
| Fixing the strut mount on the vehicle | 6.5 |
| Upper nut of shock absorber | 6.5 |
| Screws for fixing the shock absorber to the pivot | 5.4 |
| Stabilizer link | 4.5 |
| Wheel bolt | 9 |



All mounting of the MK184 reference after 08/2004, results in squeaking noise, or a breakage of the strut mount kit.