

Anziehvorschrift Zylinderkopf**Tightening Instructions for Cylinder Head****Instructions de serrage pour culasse****Prescripciones de apriete para culatas****591.190**passend für / suitable for
adaptable à / adaptable a**Dodge/Jeep****Das Original**Schraubenkopf / Head shape Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete
Tête de vis / Cabeza de tornillo

Anziehen/ Tightening/ Serrage/ Apriete	<ul style="list-style-type: none"> ⊙ M11 1-10 / 15 ft-lb M11 1-10 / 35 ft-lb M8 11-14 / 18 ft-lb ➤ M11 1-10 / 90° M8 11-14 / 22 ft-lb 	<ul style="list-style-type: none"> M11 1-10 / 20 Nm M11 1-10 / 48 Nm M8 11-14 / 25 Nm M11 1-10 / 90° M8 11-14 / 30 Nm
---	--	--

Zeichenerklärung / Explanations / Explication / Explicacion

	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
*	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

Dodge Dakota 2003-2000 4.7L V8 287cid

Dodge Ram 1500 2003-2002 4.7L V8 287cid

Jeep Grand Cherokee 2003-1999 4.7L V8 287cid

Dodge Durango 2003-2000 4.7L V8 287cid

Elring-Serviceteam

Fon +49 7123 724 799

Fax +49 7123 724 798

service@elring.de

24/01/22

591.190