

BG

Ръководство за инсталиране

Електрическа горивна помпа Bosch

CZ

Návod k instalaci

Elektrické palivové čerpadlo Bosch

D

Installationsanleitung

Bosch Elektro-Kraftstoffpumpe

E

Instrucciones de instalación

Bomba de combustible eléctrica Bosch

F

Instructions d'installation

Pompe électrique à carburant Bosch

GB

Installation instructions

Bosch electric fuel pump

H

Telepítési útmutató

Bosch elektromos üzemanyag-szivattyú

I


Istruzioni per l'installazione

Elettropompa carburante Bosch







J

取付説明書

Bosch 電動フェューエルポンプ



Обхват на доставката
Rozsah dodávky
Lieferumfang
Volumen de suministro
Contenu de la livraison
Delivery specification
Szállítási terjedelem
Fornitura
納入品



BOSCH

0 986 580 B22

NL

Installatiehandleiding

Elektrische brandstofpomp van Bosch

P

Manual de instalação

Bomba de combustível elétrica Bosch

PL

Instrukcja montażu

Elektryczna pompa paliwa Bosch

RC

安装说明

博世电动燃油泵

RO

Instrucțiunile de instalare

Pompă electrică de carburant Bosch

RUS

Инструкция по установке

Электрический топливный насос Bosch

S

Installationsinstruktion

Bosch elbränslepumpar

SK


Návod na montáž

Elektrické palivové čerpadlo Bosch







TR

Kurulum talimatı

Bosch elektro yakıt pompası



Leveringsomvang
Âmbito do fornecimento
Zakres dostawy
供货范围
Volumul de livrare
Комплект поставки
Leveransomfattning
Rozsah dodávky
Teslimat kapsamı



BOSCH

0 986 580 B22

